



Insulation Fact Sheet

This is Spray-applied Polyurethane Foam Insulation

Insulation Thickness (inches)	R-value		
	Bayseal™ OC	Bayseal™ CC X	Bayseal™ CC XP
1	3.7	6.9	6.9
3.5	13	24	24
5.5	20	38	38
7.25	26	50	50
10	35	69	69
12	42	83	83
16	56		

Read This Before You Buy

What You Should Know About R-values

The chart shows the R-value of this insulation. R means resistance to heat flow. The higher the R-value, the greater the insulating power. Compare insulation R-values before you buy. There are other factors to consider. The amount of insulation you need depends mainly on the climate you live in. Also, your fuel savings from insulation will depend upon the climate, the type and size of your house, the amount of insulation already in your house, and your fuel use patterns and family size. If you buy too much insulation, it will cost you more than what you will save on fuel. To get the marked R-value, it is essential that this insulation be installed properly.

Manufacturer:
Bayer MaterialScience LLC
2400 Spring Stuebner Rd
Spring, TX
1.800.221.3626
Tel 281.350.9000
Fax 281.288.6450
www.spf.bayermaterialscience.com